

Sunter Vanity Mirror Bulb Replacement/Troubleshooting Guide

BULB INSTALLATION AND REPLACEMENT

1. In the event that the LED bulb should fail, contact customer service at:
customerservice@blackstoneltd.com
1-888-525-7969 for a replacement bulb.
2. See bulb replacement instructions below.



Fig. 1 Unscrew for bulb access

CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 5 MINUTES BEFORE REPLACING BULB.

1. Unscrew the two side screws on the mirror head (Fig. 1).
2. Carefully remove the mirror head housing.
3. Unscrew light bulb and replace with new light bulb.
NOTE: 8 watt LED 60Hz 0.15A
4. Replace mirror head by lining up the screw holes and screw into place.
5. Plug the lamp into the AC outlet.

Directions:

- 1) Unscrew the two side screws on the mirror head:



2) Carefully remove the magnified mirror head panel:



3) Unscrew the bulb and replace with an 8 watt LED 60Hz 0.15A bulb.



*If troubleshooting a mirror that will not illuminate, tighten the bulb in the socket and replace magnified mirror head panel. Once the panel is secured, plug the mirror back in press the on/off button. If the mirror does not illuminate, please call 1-888-525-7969 to request a replacement.

- 4) Replace the magnified mirror panel by lining up the screw holes and screw into place



If you require further assistance, please contact our 24-hour customer support line at: 1-888-525-7969